



## MOUNTING INSTRUCTION

### STEP1

- \* FOLD TEMPLATE ALONG DOTTED LINE.
- \* PLACE TEMPLATE AGAINST DOOR AND HEAD FRAME.
- \* DRILL HOLES AS INDICATED ON TEMPLATE.

### STEP2

- \* MOUNT THE ARMATURE PLACE TO THE DOOR USING 1 RUBBER WASHER SANDWICHED BETWEEN 2 STEEL WASHERS (THE RUBBER WASHER AND 2 STEEL WASHERS ARE INSTALLED ON THE THROUGH SEX NUT BETWEEN THE ARMATURE PLACE AND DOOR).

### STEP3

- \* DETACH MOUNTING PLATE TO DOOR USING 2 SOCKET CAP SCREWS. SCREWS COULD BE ACCESSED THROUGH BOTTOM OF MAGNET.
- \* INSTALL THE MOUNTING PLACE WITH 2 FLAT HEAD SCREWS (THE 2 M5\*15 FLAT HEAD SCREWS ARE INSTALLED IN THE SLOTTED HOLES FOR ADJUSTMENT)
- \* ADJUST MOUNTING PLATE SO THAT IT AND THE ARMATURE PLACE FORM A RIGHT ANGLE
- \* USING THE MOUNTING PLACE AS A TEMPLATE DRILL THE WIRE HOLE
- \* DRILL AND INSTALL THE REMAINING MOUNTING SCREWS

### STEP4

- \* INSTALL MAGNET TO MOUNTING PLACE WITH 2 M6 SCREWS SUPPLIED.

### STEP5

- \* INSTALL ELECTRICAL WIRING PER INSTRUCTION SHEET.

### STEP6

- \* TEST ALL FUNCTIONS OF THIS MODEL (SEE WIRING INSTRUCTION).

### STEP7

- \* INSERT 2 LOCKING STOPPER IN TWO END PLATES, AND COVER WITH 4mm SCREWS.

### STEP8

- \* INSERT 2 ALUMINUM CAPS ON TWO SIDE M6 SCREW HOLES.